











GENESPEED®



	
<p>CAUTION Please fix the rotor firmly with the nut for rotor fixing.</p>  	<p>CAUTION Please be careful not to get your hands caught into the door or the bottom of the centrifuge.</p> 
 <p>Emergency Door Open</p>	



4.

5.

6.

7.

8.

9.

10.

11.

12.

13.

14.

15.


16.







-
-
-



to open the door when power is gone off, please refer to '75Emergency Door Release' .


-
-
-
-












-
- Only use appropriate centrifugal tubes and do not exceed the speed beyond the tube' s max









?	?	?
9,000 xg	8,000 xg	10,000 xg
		
		1,000 xg


Check the g-force of sample containers!





☒

👉 For safety, the 'Imbalance Cutoff' function is



- RPM/RCF
- TIME
- PROG
- START/STOP
- DOOR
- SOFT START /STOP









[▲▼] buttons pressed over 5





- While running, the START LED' is turned on.





1.



2.



3.



4.







GENESPEED®

